



MANAGE UP TO 1209 DVDs/CDs



SEARCH YOUR MEDIA



PLAY INTERNET RADIO



GET ENHANCED
ENTERTAINMENT
SERVICES



STREAM DIGITAL MUSIC

Quick Setup

1. Unpack Your New FireBall DVDM-100

- Unpack the FireBall, cables, and accessories (save the box).
- Install the included batteries into the remote and keyboard.
- Make note of the serial number (located on the back).

SERIAL NUMBER:

2. Connect FireBall to your Home Theater

- Locate the included composite video and analog audio cables.
- Connect FireBall to the "DVD" or other available A/V input on your receiver or TV.

Note: You may use optional s-video or component video cables and optional digital audio cables for the best picture and sound quality. This is also applicable to the next step, connecting changers to your FireBall. Contact your Escient dealer for more information.

3. Connect Changers to your FireBall


- Locate the composite video and analog audio cables included with your changer.
- Connect the composite video output from the first changer to the composite video input 1 on FireBall.
- Connect the analog audio cables from the first changer to the FRONT LEFT and RIGHT inputs of the first 5.1 analog audio input on FireBall.
- Locate the included RS-232 serial cable and 1/8" stereo S-Link/IR cable.
- Connect the RS-232 serial cable from the first changer to COM port 1 on FireBall.
- Connect the S-Link/IR cable from the "DVD-Control" jack on Kenwood changers to the S-Link/IR input 1 on FireBall. **DO NOT CONNECT FOR SONY DVD CHANGERS**
- Repeat steps **A-F** for each additional changer using video, audio, COM, and S-Link/IR ports number 2 and 3 on FireBall.

4. Connect FireBall to the Internet

Note: FireBall requires an Internet connection to identify the discs in connected changers, to provide additional entertainment services, and for general system maintenance.

- If you have a Dialup Internet Service Provider, connect the included telephone cable from FireBall's modem jack to an in wall phone jack in your home.
- If you have a broadband (cable, DSL, ISDN) Internet Service Provider, connect the included ethernet cable from FireBall's ethernet jack to your ethernet network.

Note: You may need to purchase additional network hardware such as a "router". Please contact your Escient dealer for more information.



5. Power Up!

- Plug each changer into an AC outlet.
- Plug FireBall into an AC outlet.
- The Standby LED on the front of the FireBall will begin to flash RED during the power on cycle. When the LED turns solid RED, the FireBall is ready for use.
- Press the power button on the front panel or on the remote control. The LED will turn solid BLUE and video will be displayed on the TV when the unit is on.

Note: You may have to press the "FB1" button on the remote to configure it to control FireBall. Also be sure the TV and receiver are turned on and set to the correct FireBall input.

6. Quick Start

- Use the remote control and follow the on-screen instructions.



MANAGE UP TO 1209 DVDs/CDs



SEARCH YOUR MEDIA



PLAY INTERNET RADIO




GET ENHANCED
ENTERTAINMENT
SERVICES




STREAM DIGITAL MUSIC

Remote Overview



On-Screen Interface Overview

GUIDE



Movies Guide - Browse and manage your Movie collection

PLAYER



Movie Player - display full screen video (watch a movie)

OPTIONS



Movie Options - allows you to create custom groups, edit disc information and access other movie features

SETUP



Setup Menus - set user preferences and configure external changers

OG EXPERIENCE




Escent's OpenGlobe Entertainment Services - allows you to discover more information about your favorite actors, artists, movies and music such as reviews, biographies, filmographies, discographies, influences and similar artists. You can also purchase music and movies using your FireBall DVDM-100.

MOVIES

MUSIC

iRADIO




Music Guide - Browse and manage your Music collection



Music Player - display and control the currently playing music title



Music Options - allows you to create playlists and groups, edit disc information and access other music features



iRadio Guide - browse and manage Internet Radio stations



iRadio Player - displays the currently playing iRadio station, location, channels and speed (if available)



iRadio Options - allows you to create custom groups, tune new stations and access other iRadio features

Watch a Movie

- Press the Movies key on the remote.
- Highlight the Movie you want to watch.
- Press Play.
- The movie will load and play.

Listen to Your Music

- Press the Music key on the remote.
- Highlight the Music Title you want to listen to.
- Press Play.
- The music begins to play.

Note: The DVDM-100 can play MP3 files from a FireBall Music Server connected via a home network. See manual for details.

Listen to an Internet Radio Station

- Press the iRadio key on the remote.
- Highlight the Station you want to listen to.
- Press Play.
- FireBall will connect and begin to stream (play) the station.

Discover More About Movies and Music

- Press the key on the remote.
- Select the Now Playing button on screen.
- Navigate the screens to discover more information about music and movies.